



## L-700, L-A700, L-75 Series Louvers

Fits 1 3/8" to 2 1/4" thick door.

### Installation Instructions for Louvers with frame (L-700-B, L-700-BF, L-A700-B, L-A700-BF, L-75B, L-75BF)

1. Cut out door in accordance with door manufacturers procedure.
2. Position outer frame with louver core, in door cut out, insert and start all screws before fully tightening.
3. Tighten screws using a crisscross pattern. Use caution when using power screw driving equipment to avoid stripping the material.
4. Position inner frame (L-700-BF, L-A700-BF, L-75-BF only) and secure to door using the same procedure

### Installation Instructions for Louver Cores (L-700-A, L-700-C, L-A700-A, L-A700-C, L-75-A)

1. Cut out door in accordance with door manufacturers procedure.
2. Install molding or glass stop type material on one side of where louver is to be mounted.
3. Position louver core and install molding or glass stop type material on other side to hold louver securely in place.

**FIELD PAINTING: For best results scuff finish with a scotch-brite pad prior to painting.** 11/07

