

# National Guard Products Inc.

1-800-  
647-7874



## Interlocking Ramp Assembly

### Installation Instructions

1. Assemble ramp by interlocking sections together.
2. Cut ramp to fit.
3. Position return closed end (if ordered) on each side of ramp.
4. Drill and counter sink screw holes in ramp aligned with holes in RCE.
5. Install ramp with screws provided.
6. Caulk around base of ramp and RCE for moisture control.



UL 10C Positive  
Pressure Tested  
Gasketing Material for  
Fire Doors. Also  
Classified in accordance with  
UBC 7-2 (1997).



UL10B  
Gasketing  
Materials for  
Fire Doors.

Intended for Application to  
Classified Steel type fire  
doors rated up to 3 hours and  
Wood type fire doors up to 1  
1/2 hours. 4/07